

# COMPRESSOR MUST BE RUNNING TO TEST!

PLACE BLACK PROBE ON GROUND

METER MUST READ 12 VOLTS MINIMUM

PLACE RED PROBE ON SWITCH SPADE

13.48

Method for checking voltage to Tru Count air compressor

Locate a suitable ground for the system. If a good ground is not available please strip a tiny amount of insulation from the ground wire as shown

Connect the compressor to power and turn it on.

Using a volt meter, place the red probe on either of the spades on the pressure switch and place the black probe on the ground.

The volt meter MUST read 12 volts or more.

If you do not have a minimum of 12 volts, check your connections or try a different location for your power connection. Connecting straight to the battery is always best.

Failure to deliver 12 volts minimum to the compressor will cause poor performance and substantially shorten compressor life.